



aerialBox
T1000n

User Manual





Contents:

Important Safety Instructions

Precautions

Identify Your Set Top Box

Remote Control

1. Initial Install

2. Main Menu

2.1 Installation

2.1.1 Channel Filter

2.1.2 Country

2.1.3 LCN

2.1.4 Auto Search

2.1.5 Manual Search

2.2 Channel

2.2.1 Channel Manager

2.2.2 Favorite List

2.3 Preference

2.4 Setting

2.4.1 Timers

2.4.2 Child Lock

2.4.3 Date/ Time

2.4.4 Factory Reset

2.4.5 Upgrade

2.4.6 Version

2.4.7 Auto Standby

2.5 AV

2.6 Game

3. Media

3.1 Movie

3.2 Photo

3.3 Music

4. Convenient Functions

4.1 Ways to Select Programs

4.2 Program Information

4.3 EPG

4.4 Audio

4.5 Subtitle

4.6 Recording

5. Troubleshooting

6. Warranty

Important Safety Instructions:

1. Read, Follow and Keep these Instructions.
2. Do not use this unit near water.
3. Clean only with a damp cloth. Remember to unplug power prior to cleaning.
4. Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.
5. Do not install near any heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
6. Protect the power cord from being walked on or pinched, particularly at the plug/ receptacles and the point where they exit from the unit.
7. Unplug this unit during lightning storms or when unused for long periods of time.
8. Refer all servicing to qualified personnel.
Servicing is required when the unit has been damaged in anyway; such as...
 - when the power supply or plug is damaged.
 - liquid has been spilled into the unit.
 - objects have fallen into the unit.
 - the unit has been exposed to rain or moisture.
 - unit does not operate normally.
 - unit has been dropped.

WARNING: To reduce risk of fire or electric shock, do not expose unit to rain or moisture.

Precautions:

Please read these precautions before operating this unit.

1. Power Cord Protection

To avoid any malfunctions of the unit and to protect against electric shock, fire or personal injury, please observe the following...

- Hold plug firmly when connecting/disconnecting AC power cord.
- Keep AC power cord away from heated appliances.
- Never put any heavy object on the AC power cord.
- Do not attempt to repair the AC power cord in any way.
- Never make or change connections with power switched on.

2. Placement

Avoid placing the unit in areas of:

- Direct sunlight or heat sources.
- High temperature (over 35 °C) or high humidity (over 90%).

3. Non-use Periods

When the unit is not being used, turn it off. When not used for a long period of time, the unit should be unplugged from the power source.

4. No Fingers/Objects Inside

- Touching internal parts of this unit is dangerous, and may cause serious damage to the unit.
- Do not attempt to disassemble the unit.
- Do not put any foreign objects in this unit.

5. Keep Away From Water

- Keep the unit away from flower vases, tubs, sinks, etc...
if liquids are spilled into the unit, serious damage could occur.
- If the unit has been exposed to moisture do not operate the unit.

Identify Your Set Top Box:

T1000n Front Panel



01: POWER BUTTON

02: USB PORT Firmware Upgrade & USB Device Connection



03: ANT IN UHF Aerial Input

04: LOOP OUT UHF Signal Output

05: COAXIAL Digital Audio Out

06: HDMI PORT High Definition Output

07: L/R AUDIO Audio Output


08: COMPONENT Pb, Pr & Y, for connection to a non-HD TV

09: VIDEO AV Video Output

00: POWER LEAD Connects to Power

Remote Control:

01. POWER: Turn On/Off
02. Number Keys: <0-9>
03. RECORD: TV Program Recording
04. EPG: Electronic Program Guide
05. MENU: Enter Main Menu
06. Direction Keys: Up/Down/Left/Right
07. VOL +/-: Adjust Volume
08. R/G/Y/B Keys: Function Keys
09. SUBTITLE: Select Subtitles
10. TTX: Teletext
11. TIMESHIFT: Starts Timeshift
12. GOTO: Set time of playing for Media
13. PAUSE/PLAY Program Playback
14. STOP: Stop Program Playback
15. MUTE: Toggle Sound On/Off
16. INFO: Information Window
17. RECALL: Go to Prev Channel
18. AUDIO: Audio Mode Operation
19. EXIT: Returns to Live TV
20. P+/P-: Go Next/Previous Channel
21. TV/RADIO: Switch between Modes
22. MEDIA: Media Player Mode
23. NEXT: Next Chapter
24. PREV: Previous Chapter
25. Fast Forward
26. Rewind



Connection to Aerial & TV:

Connect the cable that comes from your Aerial to the ANT IN socket in the back of your unit. Connect the AV cable that came with your unit between the yellow, red and white sockets on the back panel of the unit and your TV. Or you can use an HDMI cable if you have one.

1. Initial Install

Follow on screen instructions...

1. Plug in your **Dish TV T1000n** unit.
2. Turn on your TV and select the correct corresponding input.
3. Select correct info according to your setup, by pressing **<up/down>** and **<ok>** to confirm.
4. Select "Start Search" and press **<ok>** to search for channels.

NOTE: Once search has finished, a random channel will be shown.



2. Main Menu

2.1 Installation

Menu>Installation

Press **<menu>** for Main Menu.

Press **<ok>** on Installation.

Enter Password (Default Password 0000) to access.



2.1.1 Channel Filter

Menu>Installation>Channel Filter

Press **<menu>** for Main Menu.

Press **<ok>** on Installation.



2.1.2 Country

Menu>Installation>Country

Change country location.

2.1.3 Logical Channel Numbering

Menu>Installation>LCN

It is best set to **<on>**.

2.1.4 Auto Search

Menu>Installation>Auto Search

Press **<ok>** to select Auto Search.

A window will appear. Highlight "Yes" and press **<ok>** to delete all channels and start channel search to re-install. Once search has finished, a random channel will be shown.



2.1.5 Manual Search

Menu>Installation>Manual Search

Press **<ok>** to select Manual Search.

Use this option to scan individual frequencies.

Set corresponding frequency and bandwidth.

Select "Start Search" and press **<ok>** to start searching.



2.2 Channel

Menu>Channel



2.2.1 Channel Manager

Menu>Channel>CH. Manager

Press **<up/down>** to select any channel listed. Four Functions are available, **LOCK, DELETE, SKIP, RENAME**.



LOCK: Press **<RED>** key to LOCK channel. (Default Password 0000). User will now need to enter Password to view locked channel.

DELETE: Press **<GREEN>** key to DELETE channel. (Default Password 0000). You will be asked to confirm, select "Yes" to delete it.

SKIP: Press **<YELLOW>** key to set SKIP status. Press again to toggle off. This channel will now be skipped when using **<CH-/CH+>**.

RENAME: Press **<BLUE>** to enter the editing window. You will have the option to change the name of the channel.

2.2.2 Favorite List

Menu>Channel>Favorite List

Set channels to Favorite Lists (1-4).

Press **<RED>** to add to First FAV List.
Press **<GREEN>** for Second FAV List.
Press **<YELLOW>** for Third FAV List.
Press **<BLUE>** for Fourth FAV List.



After setting channels to FAV Lists, user can hold down **<FAV>** on the remote to access them quickly.

2.3 Preference

Menu>Preference



OSD Language: Set on-screen Language that will be displayed.

OSD Timeout: Set the length of time Banners are displayed (Range 1-6 seconds).

Time On OSD: Option to turn on/off permanent on-screen clock.

OSD Transparency: Select transparency of on-screen window (Range 0%-60%).

1st Preferred Subtitle: Select preferred default subtitle language.

2nd Preferred Subtitle: Select backup subtitle language, incase 1st Preferred is not available.

Preferred Teletext: Set preferred default teletext language.

Hard Of Hearing: Turn audio descriptive on/off.

1st Preferred Audio: Select preferred default audio language.

2nd Preferred Audio: Select backup audio language, incase 1st Preferred is not available.

PVR Config: Set recording data; like... file format, file size, file storage position and time shift.

2.4 Setting

Menu>Setting



2.4.1 Timers

Menu>Setting>Timers

This option is used for multi-timer recordings or setting a channel to be displayed at a certain time etc...

RECORDING, requires an External USB Device to be connected.

Press **<YELLOW>** or **<ok>** to edit/
enter the timer window.

NOTE, make sure the **<ok>** key is pressed to save data or press the **<exit>** key to cancel setting timer. User can put unit into standby, and unit will turn on automatically to start any set timer recordings.

Date: Select date you would like timer to begin.

Program Name: Select channel you would like recorded or displayed.

Start Time: Select time you wish timer to start.

End Time: This will change according to duration selected.

Duration: Select how long you wish the timer duration to be.

Mode: Select how often you wish timer to occur. The options are (Once, Daily, Weekly, Monthly).

Type: This will give you a choice of one of the following options...

On- When chosen the receiver will turn on at time and date selected.

Recorder- The receiver will start recording at time and date selected.

Channel- Receiver will change channel at time and date selected.

Standby- Receiver will turn to standby at time and date selected.

Subtitle Recorder: When set to "ON", subtitles will be included in the recording. As long as the program has subtitles available. Press the **<subtitle>** key on your remote to view subtitles during playback.

Teletext Record: When this option is set to "ON", teletext will be included in the recording.



2.4.2 Child Lock

Menu>Setting>Child Lock

When entering this option, you will be prompted for the password (Default Password 0000).

System Lock: Default is "ON", this enables Pin Code Channel Locking. If set to "OFF" all Channel Locking is disabled.

Parental Rating: Default is UNDEF (Undefined); this means there is no Parental Lock. If changed (G, PGR, AO), programs with the rating selected and above will require a password to be viewed.

Change Pin Code: Change password, (Default Password 0000).




2.4.3 Date/Time

Menu>Setting>Date/Time

Auto: The only options accessible for use are Time Zone and Day Light Saving.

Manual: Manually set the Date and Time your unit displays.

Country Region: Will default to country specified in the initial setup of your receiver. You will not be able to alter from this menu.



2.4.4 Factory Reset

Menu>Setting>Factory Reset

This will reset all settings back to factory, deleting all channels and user settings (Default Password 0000).

2.4.5 Upgrade

Menu>Setting>Upgrade

USB Upgrade: Insert a USB Device with new firmware/ software on. Select the software file on the USB Device, press **<ok>** to upgrade.



OTA Upgrade: This option can be used only if an Over The Air software update is broadcasted via the UHF transmitter. The software will only be broadcast for a few weeks if a major update is needed.

2.4.6 Version

Menu>Setting>Version

This is an information page only. Here you can find your receivers hardware/ software versions. This information is important when checking for any new updates regarding software for your unit.



2.4.7 Auto Standby

Menu>Setting>Auto Standby

(Default Setting "OFF"), when set to "OFF" the unit will not turn on to standby unless the **<power>** button is pressed. When set to "ON" you can set a length of time, after which the unit will automatically turn off (1hr, 2hr, 3hr Options).

2.5 AV

Menu>AV

In this menu, you can adjust the audio and visual preferences of your receiver.



Here you can adjust settings like **Brightness, Contrast, Saturation, Hue.**

SPDIF: Default is PCM (Uncompressed). Mute, disables audio via SPDIF output. Bitstream (Compressed) may be used if PCM is unsuitable.

Aspect Ratio: This is to set the output display shape (Full Screen, 16:9).

Video Output: Select either Composite or Component (CVBS, YUV).


Video Resolution: This is where you set the output resolution, depending on what your TV can handle. 50Hz and 60Hz options available.

HDMI Audio: Default is HDMI Raw. HDMI Mute, disables audio via HDMI output. HDMI PCM may be used if HDMI Raw is unsuitable.

2.6 Game

Menu>Game


In this menu, you will see the unit comes with five games installed; Sudoku, Go Bang, Box Man, Tetris and Hit Rat.



3. Media

Options include... Movie, Music, Photo, Game, EBook, Record Manager and Disk Manager.

NOTE: Requires an External USB Device to be connected. Some media file types may not play or be viewed. Please phone support for further information.



3.1 Movie

If there is an External USB Device connected, it will show under the Movie option. To access and browse through movies on the device. Just select it, to start. Recordings made are viewed here.




3.2 Photo

Press <ok> to start slideshow. <up/down/left/right> will change the orientation of the image. Press <next> or <prev> to view the next or previous images. <play/pause> to pause or restart the slideshow.



3.3 Music

If the USB Device is connected, it will show under the Music option. To access and browse through Music Files on the device. Just select it, to start. Press <ok> to play, <stop> to stop playback.



4. Convenient Functions

4.1 Ways to Select Programs

Currently there are 4 ways to select a desired channel.

Press **<ok>** to select a channel from the program list.

Press **<epg>** to select a channel from the Electronic Program Guide.

Press **<0-9>** to change to the corresponding channel.

Press **<ch+/ch->** to change to next or previous channel.

4.2 Program Information

To view information on current program, press **<i>** on your remote, press it again to view more detailed information. **<i/exit>** to exit.

4.3 EPG

Press **<epg>** to view the Electronic Program Guide.

When viewing "Today" press the **<YELLOW>** key to view next weeks program info. From there or any other day, pressing the **<YELLOW>** key will move to previous day in EPG.

Pressing the **<BLUE>** key will move you to the next day in EPG.

4.4 Audio

Press **<audio>** on your remote to enter the multi-audio window. Press **<left/right>** to switch between options (stereo, left, right). To select stream, use **<up/down>**. To confirm selection, press **<ok/exit>** and return to Live TV.

4.5 Subtitle

Press **<subtitle>** on your remote to access subtitle page. From here select desired option, and press **<ok>** to confirm choice and exit.

4.6 Recording

NOTE: Requires an External USB Device to be connected.

To record you can either set a Timer (2.4.1) or Instant Record **<rec>**.

Instant Record: Insert USB Device, into USB socket. Select channel you wish to record. Press **<rec>** to start recording current playing program. Press **<rec>** again to display duration window, to set how long you wish recording to go for. To stop the recording at any time, press **<stop>** and select "Yes". Press **<i>** to view recording info any time.

5. Troubleshooting

There may be various reasons for the abnormal operation of the receiver. Check the receiver according to the procedures shown below. If the receiver doesn't work properly after checking it, please contact the dealer. Don't open the receiver cover. It may cause a dangerous situation .

Front Panel Display doesn't light up:

-Make sure Power Lead is plugged in. An that Power Switch is on.

No Picture:

-Make sure that the receiver is not in standby mode.

-Check the HDMI/AV Lead is correctly connected to correct TV input.

-Check that your TV has the correct corresponding input selected.

-Make sure the UHF Antenna Cable is correctly connected to ANT IN.

No or Bad Signal Message:

-Check all antenna connections, or adjust antenna position.

-Factory default and try to re-scan the channels.

Poor Picture & Sound Quality:

-Check there is nothing obstructing the UHF Antenna.

-Due to bad interference in your area. Installing a filter may solve it.

-Check you're using RG6 Coax to an outdoor antenna, an that all the connections are good.

No or Poor Sound:

-Check the volume level of the TV.

-Check the Mute status of the TV and T1000n Receiver.

-Press the audio button to change the Sound Track type.

No Remote operation:

-To manipulate the equipment with the remote control, the control's emitting part should be directly pointing towards the receiving part (IR Sensor) of receiver.

-Replace the batteries in the remote and ensure correctly inserted.

NOTE: If the problem can not be solved by going through this Trouble Shooting Guide. Please contact Our Customer Care Centre for more additional help. Call **0800 Dish TV (3474 88)**.

6. Warranty

Please keep your receipt as proof of purchase. This product is warranted for any defect in materials or workmanship for one year after the original date of purchase. This product is for normal domestic use only. This warranty does not cover damage from misuse or neglect, accidental damage, vermin infestation, excessive voltages such as lightning or power surges or any alteration that affects the performance or reliability of the product. In the unlikely event that your product fails to work normally please contact your supplier and have your receipt of purchase on hand.

This warranty is subject to the following provisions:

- This is only valid within New Zealand.
- The product must be correctly connected and operated in accordance with the instructions contained in the manual.
- This product must be used solely for domestic purposes.
- The warranty does not cover accidental damage.
- The warranty will be rendered invalid if the product is resold or has been damaged by unauthorised repair.
- The manufacturer disclaims any liability for incidental or consequential damages.



Warranty & Product Registration

Register your product to assist with warranty and product updates.

To do this, please visit www.dishtv.co.nz

Click on warranty & registration

