

Firmware Updating Instructions T2200 – Option 1

1. Copy the T2200 Update File that was with these Instructions onto a USB Drive.
2. Insert USB Drive into USB Port on the Front or Rear of the unit.
3. Go to Menu/ Software Upgrade/ Manual Update, select “USB” from options and press “OK”.
4. Read on screen notification and enter Password (Default Password is “0000”).
5. Unit will then begin the software update, when complete it will resume normal TV viewing.

WARNING! DO NOT REMOVE POWER TO THE UNIT WHEN UPDATING

Firmware Updating Instructions T2200 – Option 2

1. Copy the T2200 Update File that was with these Instructions onto a USB Drive.
2. Power off your T2200 at the wall
3. Insert USB Drive into USB Port on the Front or Rear of the unit.
4. Hold the “Menu” Button down on the Front Panel of the T2200, reconnect the power while still holding it down.
5. After few seconds “USB” will come up on the front display, allowing you to release “Menu”.
6. Unit will then begin the software update, when complete it will resume normal TV viewing.

WARNING! DO NOT REMOVE POWER TO THE UNIT WHEN UPDATING