

## How to update your A2 via USB

1. Download the update.zip file and copy it to a USB drive. Then insert the USB into the A2.
2. Press the 'O' button on your remote.
3. Move to and select **Settings** at the top right of your screen next to the time.
4. Move down and enter the **About** menu.
5. Select **Local update** then **sdb1**.
6. You will see a message saying Copying update.zip... this can take a few mins.
7. Then select **OK** when asked **Are you sure you want to upgrade?**
8. The unit will restart and install the software